



1. Mic Connector (XLR)
2. Power/Pairing button
3. Multifunction LED
4. Volume Up
5. Volume Down
6. USB-C Charging Port
7. Audio Input (3.5mm)

Multifunction LED

Charging (orange=charging, green=charged)

Pairing (blinking= not paired, solid=paired)

Battery Low (flashing purple)

To start enjoying your new X1 Mic Transmitter:

For use with an Audality Speaker:

1. Turn the speaker volume to 100% volume (you will control volume at the X1 Mic Transmitter).
2. Turn on the power to the speaker. The blue pairing light should be blinking.
3. Turn the X1 Mic Transmitter on by pressing and holding the Power/Pairing button (2) for 3 seconds.
4. Tap the Power/Pairing button (2) to pair the Audality speaker to the X1 Mic Transmitter (the LED will stop blinking when paired).
5. Plug your XLR microphone into the X1 Mic Transmitter XLR connector (1).
6. Press the Volume Up button (4) to UNMUTE the X1 Mic Transmitter, and speak into the mic to test.
7. Plug a music source into the Audio Input (7) using the supplied cable
8. Control the music source at the source (phone, CD player, etc.).
9. Control the system volume using the Volume Up (4) and Volume Down (3) buttons.
10. Enjoy!

Tips & Hints:

- Range: The range varies depending on the environmental conditions like weather, terrain and buildings. We have gotten as much as 500 feet range.
- Placement: Our technology automatically finds the most interference-free channel, but we recommend setting up your speaker off of the ground and at least 1m away from your Wi-Fi router for optimal listening and connection.
- Start with the speaker at 100%.
- Set your Audality speaker's R/L/B switch to BOTH

What's Included:

- (1) X1 Mic Transmitter
- (1) Charging Cable
- (1) USB Charger
- (1) 3.5 mm cable

WARNING:

- No user serviceable parts inside.
- Each Unit is powered by Lithium-Ion Rechargeable Battery.
- Do not open, crush, modify, disassemble, heat above 140°F (60°C), or incinerate. Improper handling could cause batteries to explode or release toxic materials, creating risk of fire or burns